
CURTAIN SW 1
C NO
FLOAT SWITCHES
LOW
C NC
HIGH
C NC
W BL
R/W BL
BL
BL/W
REMOTE MEMBRANE SWITCH
SUMP TEMP
(OPTIONAL)
BIN STAT
C NC
GY
GY
BL
CONTROL BOX
BL (OPT.)
2 FILL
W W
BK BK
CONTROL BOARD
DIP SWITCHES
HI PRG
BIN ST
3M CL
RS-485
COMM. PORT
IN1 IN2 IN3 IN4 IN5 IN6 IN7 IN8 IN9 IN10
COM
SUMP TEMP
REMOTE SWITCH
12V DC
TRANSFORMER
CURT. SW 1
CURT. SW 2
FLOAT SW HI
FLOAT SW LO
CONFIG. 1
FILL CONFIG
REM CONFIG
CONFIG. 2
ON/OFF - POWER
LED (BLUE/RED)
CLEAN
LED (YELLOW)
FAN(S)/LIQ. LINE
CONT./COMP./REM FAN
HOT GAS/HARVEST
H2O IN
PURGE
H2O PUMP
BIN STAT
R1 K1
R2 K2
R3 K3
R4 K4
R5 K5
R6 K6
LINE VOLTAGE
FUSE
L1 L2/N R1 R2 R3 R4 R5 R6
PIN 8
PIN 1
BN BL GY BK R T PK Y
REMOTE CONDENSER
FAN
MOTOR
POWER SUPPLY
SEE NAMEPLATE FOR PROPER FUSE
OR HACR TYPE BREAKER SIZE AND
VOLTAGE REQUIREMENTS.
FUSE REQUIRED ON
BOTH SIDES OF POWER
SUPPLY FOR 200-240
VOLT UNITS
R
R
L2/N
L1
J-BOX
CAUTION
UNIT MUST
BE GROUNDED
EXTERNAL
PROTECTOR
(OPTIONAL)
COMPRESSOR
C
S
R
BL BN
R R BK
BK
POTENTIAL
RELAY
BL BL
R
Y
C1
CONTACTOR
C2
L1
L2
T1
T2
BN
BL
BL
BL
BL
RUN
CAP
START
CAP
PUMP DOWN
CONTROL
C NC
BK
BL
BN
(OPTIONAL)
OZONE P.S.
OZONE
GENERATOR
BK
HIGH PRES.
CUTOUT
C NC
BK
HIGH TEMP
CUTOUT
C NC
GN/Y
GYBL
BL R
O
BL
BL
BL BL T
BL
BLPK
BL Y
M
M
LIQUID LINE
SOL.
HOT GAS
SOL. #1
HARVEST
MOTOR #1
WATER INLET
SOLENOID
PURGE
SOLENOID
WATER
PUMP
CAUTION: DISCONNECT POWER BEFORE SERVICING
MACHINE OR ELECTRICALS
MORE THAN ONE DISCONNECT SWITCH
MAY BE REQUIRED TO DE-ENERGIZE ALL
POWER TO THE MACHINE
SHOWN IN FREEZE MODE
9072194-02
REV G