



POWER SUPPLY

SEE NAMEPLATE FOR PROPER FUSE OR HACR TYPE BREAKER SIZE AND VOLTAGE REQUIREMENTS.

FUSE REQUIRED ON BOTH SIDES OF POWER SUPPLY FOR 200-240 VOLT UNITS

CAUTION UNIT MUST BE GROUNDED

CAUTION: DISCONNECT POWER BEFORE SERVICING MACHINE OR ELECTRICALS  
 MORE THAN ONE DISCONNECT SWITCH MAY BE REQUIRED TO DE-ENERGIZE ALL POWER TO THE MACHINE

SHOWN IN FREEZE MODE