


Wiring Diagram, 115 volt, 60Hz. Basic and Water Station

ALL CONTROLS SHOWN IN
NORMAL ICE DISPENSING MODE



USE COPPER CONDUCTORS ONLY