



SERVICE PARTS MANUAL

ICE SERIES CUBERS

MODEL-ICE0250A1,A2,A3-T1,T2,T3-W1,W2,W3

MODEL-ICE0400A1,A2-T1,T2-W1,W2

MODEL-ICE0500A1,A2-T1,T2-W1,W2-R1,R2,R3

MODEL-ICE0606A1,A2-T1,T2-W1,W2-R1,R2,R3

Includes 50Hz. and 3 Phase Units



14-1006

Date 06/18/2025

ICE Series Service Parts **RED=No Longer Available**

This parts list contains the service parts available for the ICE Series icemakers.


Check the model number on the data plate and refer to the correct listing for the specific component.

Check carefully that the correct part is identified and ordered.

Table of Contents	Page 1
Exterior Components	Page 2 - 3
Interior Components-Front View	Page 4 - 5
Air Cooled	Page 6 - 7
Water Cooled	Page 8 - 9
Remote	Page 10 - 11
Control Box	Page 12 - 13
Specific Compressor Components	Page 13
Harvest Assist Assembly	Page 14 - 15
Remote Condenser	Page 16 - 17

The ICE Series Service manual is available separately, Part number 9081270-01

Ice-O-Matic
11100 East 45th Ave.
Denver Co. 80239
800-423-3367




ICE Series Service Parts

Exterior Components

Item	Model Number					Description
No.	ICE0250	ICE0400	ICE0406	ICE0500	ICE0606	
1	2101285-01	2101285-01	2101285-01	2101285-01	2101285-01	*Top Panel NLA
1	2101280-01	2101280-01	2101280-01	2101280-01	2101280-01	*Top Panel- Top Discharge NLA
2	9031098-02	9031098-02	9031098-02	9031098-02	9031098-02	Top Panel Screw (-02P for 25pk)
3	2031465-01	2031465-01	2031465-01	2031465-01	2031465-01	*Front Panel NLA
4	9031098-02	9031098-02	9031098-02	9031098-02	9031098-02	Front Panel Screw (-02P for 25pk)
5	3021770-01	3021770-01	3021770-01	3021770-01	3021770-01	*LH Side Panel NLA
6	9031046-03	9031046-03	9031046-03	9031046-03	9031046-03	Side Panel Screws (-03P for 10pk)
7	9031141-01	9031141-01	9031141-01	9031141-01	9031141-01	Plastic Nut Insert (-01P for 25pk)
8	2031468-01	2031468-01	2031468-01	2031468-01	2031468-01	*RH Side Panel- Louvered NLA
9	3012681-01	3012681-01	3012681-01	3012681-01	3012681-01	Junction Box Cover NLA
10	9031046-01	9031046-01	9031046-01	9031046-01	9031046-01	Jun.Box Cvr Screw (-01P for 10pk)
11	3021774-01	3021774-01	3021774-01	3021774-01	3021774-01	*RH Side Panel NLA
12	3021742-01	3021742-01	3021742-01	3021742-01	3021742-01	Rear Panel
13	9031046-01	9031046-01	9031046-01	9031046-01	9031046-01	Rear Panel Screw (-01P for 10pk)
14	3012905-01	3012905-01	3012905-01	3012905-01	3012905-01	Control Box Top Cover
15	3012904-01	3012904-01	3012904-01	3012904-01	3012904-01	Control Box Side Cover NLA
16	9031046-01	9031046-01	9031046-01	9031046-01	9031046-01	Control Box Screws (-01P for 10pk)
17	3012893-01	3012893-01	3012893-01	3012893-01	3012893-01	Water Trough Support NLA

Item	Model Number			Description
No.	ICE0305	ICE0405	ICE0605	
1	2101285-01	2101285-01	2101285-01	*Top Panel NLA
1	2101280-01	2101280-01	2101280-01	*Top Panel- Top Air NLA
2	9031098-02	9031098-02	9031098-02	Top Panel Screw (-02 for 25pk)
3	2031465-01	2031465-01	2031465-01	*Front Panel NLA
4	9031098-02	9031098-02	9031098-02	Frt Pan. Screw (-02p for 25pk)
5	3021770-01	3021770-01	3021770-01	*LH Side Panel NLA
6	9031046-03	9031046-03	9031046-03	Sd Pan. Screws (-03p for 10pk)
7	9031141-01	9031141-01	9031141-01	Plas.Nut Insert (-01 for 10pk)
8	2031468-01	2031468-01	2031468-01	*RH Panel- Louvered NLA
9	3012681-01	3012681-01	3012681-01	Junction Box Cover
10	9031046-01	9031046-01	9031046-01	Jun.Box Cvr Screw (-01p = 10pk)
11	3021774-01	3021774-01	3021774-01	*RH Side Panel NLA
12	3021742-01	3021742-01	3021742-01	Rear Panel
13	9031046-01	9031046-01	9031046-01	R.Panel Screw (-01P for 10pk)
14	3012905-01	3012905-01	3012905-01	Control Box Top Cover
15	3012904-01	3012904-01	3012904-01	Control Box Side Cover NLA
16	9031046-01	9031046-01	9031046-01	Ctrl Box Screws (-01P for 10pk)
17	3012893-01	3012893-01	3012893-01	Water Trough Support NLA

***Note: Cabinet Panels are NO LONGER AVAILABLE**




ICE Series Service Parts

Front Interior

Item		Model Number				Description
No.	ICE0250	ICE0400	ICE0406	ICE0500	ICE0606	
1	2021524-01	2021524-01	2021524-01	2021524-01	2021524-01	Left Hand Frame Panel NLA
2	2021649-01	2021649-01	2021649-01	2021649-01	2021649-01	Right Hand Frame Panel NLA
3	2051156-81A	2051148-81A	2051148-81A	2051148-81A	2051148-81A	Evaporator-Full Cube
	2051156-82A	2051148-82A	2051148-82A	2051148-82A	2051148-82A	Evaporator-Half Cube
4	9051154-07	9051154-08	9051154-08	9051154-08	9051154-08	Evaporator Splash Curtain
5	2041338-01	2041338-01	2041338-01	2041338-01	2041338-01	Water Distribution Tube
6	9031122-01	9031122-01	9031122-01	9031122-01	9031122-01	Thumb Screw (-01P for 10pk)
7	9031004-19	9031004-19	9031004-19	9031004-19	9031004-19	Rubber Washer (-01P for 10pk)
8	9041111-01	9041111-01	9041111-01	9041111-01	9041111-01	High Pressure Control
9	9021010-04	9021010-04	9021010-04	9021010-04	9021010-04	Clamp (-04P for 25pk)
10	9051142-02	9051142-01	9051142-01	9051142-01	9051142-01	Water Pump Tube
11	9161076-01	9161076-01	9161076-02	9161076-01	9161076-02	Water Pump
	3012509-01	3012509-01	3012509-01	3012509-01	3012509-01	Water Pump Bracket
12	9131111-101	9131111-101	9131111-101	9131111-101	9131111-101	Float, Includes Fittings
13	6021032-01	6021032-01	6021032-01	6021032-01	6021032-01	Water Float Tube (26")
14	9051001-09	9051001-09	9051001-09	9051001-09	9051001-09	Snap Bushing (-09P for 10pk)
15	9051537-01	9051537-01	9051537-01	9051537-01	9051537-01	Water Return Trough
16	9031046-24	9031046-24	9031046-24	9031046-24	9031046-24	Wtr R.Trgh Screw (-24P for 10pk)
17	9091086-02	9091086-02	9091086-02	9091086-02	9091086-02	Valve Core (-02P for 10pk)
18	9091086-03	9091086-03	9091086-03	9091086-03	9091086-03	Valve Cap (-03P for 10pk)
19	9131026-02	9131026-02	9131026-02	9131026-02	9131026-02	Caplug
20	3012747-01	N/A	N/A	N/A	N/A	Bracket Curtain Stopper NLA
21	9031141-01	9031141-01	9031141-01	9031141-01	9031141-01	Plastic Nut Insert NLA

Item		Model Number		
No.	ICE0305	ICE0405	ICE0605	Description
1	2021524-01	2021524-01	2021524-01	Left Hand Frame Panel
2	2021523-01	2021523-01	2021523-01	Right Hand Frame Panel
3	2051156-81A	2051148-81A	2051148-81A	Evaporator-Full Cube
	2051156-82A	2051148-82A	2051148-82A	Evaporator-Half Cube
4	9051154-07	9051154-08	9051154-08	Evaporator Splash Curtain
5	2041338-01	2041338-01	2041338-01	Water Distribution Tube
6	9031122-01	9031122-01	9031122-01	Thumb Screw (-01P for 10pk)
7	9031004-19	9031004-19	9031004-19	Rubber Washer (-19P for 10pk)
8	9041111-01	9041111-01	9041111-01	High Pressure Control
9	9021010-04	9021010-04	9021010-04	Clamp (-04P for 25pk)
10	9051142-02	9051142-01	9051142-01	Water Pump Tube
11	9161076-02S	9161079-03S	9161079-03S	Water Pump
	3012509-01	3012509-01	3012509-01	Water Pump Bracket
12	9131111-101	9131111-101	9131111-101	Float, Includes Fittings
13	6021032-01	6021032-01	6021032-01	Water Float Tube (26")
14	9051001-09	9051001-09	9051001-09	Snap Bushing (-09P for 10pk)
15	9051537-01	9051537-01	9051537-01	Water Return Trough
16	9031046-24	9031046-24	9031046-24	Wtr R. Trgh Screw (-24P for 10pk)
17	9091086-02	9091086-02	9091086-02	Valve Core (-02P for 10pk)
18	9091086-03	9091086-03	9091086-03	Valve Cap (-03P for 10pk)
19	9131026-02	9131026-02	9131026-02	Caplug
20	3012747-01	N/A	N/A	Curtain Stopper NLA
21	9031141-01	9031141-01	9031141-01	Plastic Nut Insert NLA



ICE Series Service Parts


Air Cooled

Item No.	Model Number					Description
1	9181117-11	9181086-11	9181086-12	9181085-12	9181112-11	Compressor RED=NLA
1	9181121-11					Compressor (Revision 2 and Above)
2	9151123-03	9151123-03	9151123-04	9151123-03	9151123-04	Hot Gas Valve Coil
3	9151123-01	9151123-01	9151123-01	9151123-01	9151123-01	Hot Gas Valve Body (-101 for Kit)
4	9041104-101A	9041104-101A	9041104-101A	9041104-101A	9041104-101A	Low Pressure Control
5	9151163-01	9151163-01	9151163-01	9151163-01	9151163-01	Filter Drier
6	9041105-01	9041105-01	9041105-02	9041105-01	9041105-02	Purge Valve - 9041086 is NLA
6.1	9041105-101	9041105-101	9041105-101	9041105-101	9041105-101	Purge Valve Mounting Bracket
7	9091074-01	9091074-01	9091074-01	9091074-01	9091074-01	Drop Adapter
8	9091083-01	9091083-01	9091083-01	9091083-01	9091083-01	Water Inlet Fitting
9	9091140-01	9091140-01	9091140-01	9091140-01	9091140-01	Purge Drain Fitting
10	9021010-04	9021010-04	9021010-04	9021010-04	9021010-04	Clamp (-04P for 25pk)
11	9151006-16	9151006-08	9151006-08	9151006-08	9151006-08	Expansion Valve NLA
11	9151154-101					Expansion Valve (Beg. Ser. F3)
11		9151149-101	9151149-101	9151149-101		Expansion Valve (Beg. Ser. K1)
11					9151151-101	Expansion Valve (Beg. Ser. B2)
12	9051280-06	9051280-06	9051280-06	9051280-06	9051280-06	Purge Drain Hose NLA
13	6021032-01	6021032-01	6021032-01	6021032-01	6021032-01	Tube (2.17 Ft.)
14	9021010-04	9021010-04	9021010-04	9021010-04	9021010-04	Clamp (-04P for 25pk)
15	9041087-03	9041087-03	9041087-03	9041087-03	9041087-03	High Temp Safety NLA
16	9141104-01	9141106-01	9141106-01	9141113-01	9141113-01	Air Condenser
16				9141120-01		Air Cond Beg Ser E217-07212-Z
16					9141120-01	Air Cond Beg Ser F2
17	1051209-01	1051209-01		1051209-01		Fan Motor Kit
17			1051209-03		1051209-03	Fan Motor Kit
18	NLA	NLA	NLA	NLA	NLA	Fan Blade NLA as a separate part
19	NLA	NLA	NLA	NLA	NLA	Fan Motor Bracket NLA as a separate part
17						
18						
19						
20	3013112-01	3013112-01	3013112-01	3013112-01	3013112-01	Fan Shroud NLA

Note: When installing a 9041105 Series Purge Valve the 9041105-101 Mounting Bracket is required.

No.	ICE0305	ICE0405	ICE0605	Description
1	9181088-11	9181088-11	9181112-12	Compressor RED=NLA
2	9151123-04	9151123-04	9151123-04	Hot Gas Valve Coil
3	9151123-01	9151123-01	9151123-01	Hot Gas Valve Body
4	9041104-101A	9041104-101A	9041104-101A	Low Pressure Control
5	9151163-01	9151163-01	9151163-01	Filter Drier
6	9041105-02	9041105-02	9041105-02	Purge Valve - 9041086 is NLA
6.1	9041105-101	9041105-101	9041105-101	Purge Valve Mounting Bracket
7	9091074-01	9091074-01	9091074-01	Drop Adapter
8	9091083-01	9091083-01	9091083-01	Water Inlet Fitting
9	9091140-01	9091140-01	9091140-01	Purge Drain Fitting
10	9021010-04	9021010-04	9021010-03	Clamp (9021010-03 is NLA)
11	9151006-16	9151006-08	9151006-08	Expansion Valve NLA
11	9151154-101			Expansion Valve (Beg. Ser. F3)
11		9151149-101		Expansion Valve (Beg. Ser. K1)
11			9151151-101	Expansion Valve (Beg. Ser. B2)
12	9051280-06	9051280-06	9051280-06	Purge Drain Hose NLA
13	6021032-01	6021032-01	6021032-01	Tube (2.17 Ft.)
14	9021010-04	9021010-04	9021010-04	Clamp (-04P for 25pk)
15	9041087-03	9041087-03	9041087-03	High Temp Safety NLA
16	9141106-01	9141106-01	9141113-01	Air Condenser
16	9141104-01			Air Cond Beg Rev 2 NLA
17	1051209-02	1051209-02	1051209-02	Fan Motor Kit
18	NLA	NLA	NLA	Fan Blade NLA
19	NLA	NLA	NLA	Fan Motor Bracket NLA
20	3013112-01	3013112-01	3013112-01	Fan Shroud NLA

Note: When installing a 9041105 Series Purge Valve the 9041105-101 Mounting Bracket is required.



ICE Series Service Parts


Water Cooled

Item	Model Number					Description
No.	ICE0250	ICE0400	ICE0406	ICE0500	ICE0606	
1	9181117-11	9181086-11	9181086-12	9181085-12	9181112-11	Compressor RED=NLA
1	9181121-11					Compressor Beg. Rev 2
2	9151123-03	9151123-03	9151123-04	9151123-03	9151123-04	Hot Gas Valve Coil
3	9151123-01	9151123-01	9151123-01	9151123-01	9151123-01	Hot Gas Valve Body
4	9041104-101A	9041104-101A	9041104-101A	9041104-101A	9041104-101A	Low Pressure Control
5	9151163-01	9151163-01	9151163-01	9151163-01	9151163-01	Filter Drier
6	9041105-01	9041105-01	9041105-02	9041105-01	9041105-02	Purge Valve - 9041086 is NLA
6.1	9041105-101	9041105-101	9041105-101	9041105-101	9041105-101	Purge Valve Mounting Bracket
7	9091074-01	9091074-01	9091074-01	9091074-01	9091074-01	Drop Adapter
8	9091083-01	9091083-01	9091083-01	9091083-01	9091083-01	Water Inlet Fitting
9	9091140-01	9091140-01	9091140-01	9091140-01	9091140-01	Purge Drain Fitting
10	9021010-04	9021010-04	9021010-04	9021010-04	9021010-04	Clamp (-04P for 25pk)
11	9151006-21	9151006-08	9151006-08	9151006-08	9151006-08	Expansion Valve NLA
11	9151154-101					Expansion Valve (Beg. Ser. F3)
11		9151149-101	9151149-101	9151149-101		Expansion Valve (Beg. Ser. K1)
11					9151151-101	Expansion Valve (Beg. Ser. B2)
12	9051280-06	9051280-06	9051280-06	9051280-06	9051280-06	Purge Drain Hose NLA
13	6021032-01	6021032-01	6021032-01	6021032-01	6021032-01	Tube (2.17 Ft.)
14	9021010-04	9021010-04	9021010-04	9021010-04	9021010-04	Clamp (-04P for 25pk)
15	9041087-03	9041087-03	9041087-03	9041087-03	9041087-03	High Temp Safety NLA
16	9141061-01	9141023-01	9141024-01	9141024-01	9141024-01	Water Condenser
17	9041059-01	9041059-01	9041059-01	9041059-01	9041059-01	Water Valve
18	9091063-02	9091063-02	9091063-02	9091063-02	9091063-02	Drop Adapter 1/2"

Note: When installing a 9041105 Series Purge Valve the 9041105-101 Mounting Bracket is required.


Item	Model Number			Description
No.	ICE0305	ICE0405	ICE0605	
1	9101088-11	9181088-11	9181112-12	Compressor RED=NLA
2	9151123-04	9151123-04	9151123-04	Hot Gas Valve Coil
3	9151123-01	9151123-01	9151123-01	Hot Gas Valve Body
4	9041104-101A	9041104-101A	9041104-101A	Low Pressure Control
5	9151163-01	9151163-01	9151163-01	Filter Drier
6	9041105-02	9041105-02	9041105-02	Purge Valve - 9041086 is NLA
6.1	9041105-101	9041105-101	9041105-101	Purge Valve Mounting Bracket
7	9091074-01	9091074-01	9091074-01	Drop Adapter
8	9091083-01	9091083-01	9091083-01	Water Inlet Fitting
9	9091119-01	9091119-01	9091119-01	Purge Drain Fitting
10	9021010-04	9021010-04	9021010-04	Clamp (-04 for 25pk)
11	9151006-16	9151006-08	9151006-08	Expansion Valve NLA
11	9151154-101			Expansion Valve (Beg. Ser. F3)
11		9151149-101		Expansion Valve (Beg. Ser. K1)
11			9151151-101	Expansion Valve (Beg. Ser. B2)
15	9041087-03	9041087-03	9041087-03	High Temp Safety NLA
16	9141061-01	9141024-01	9141024-01	Water Condenser
17	9041059-01	9041059-01	9041059-01	Water Valve
18	9091063-02	9091063-02	9091063-02	Drop Adapter 1/2"

Note: When installing a 9041105 Series Purge Valve the 9041105-101 Mounting Bracket is required.



Item		Model Number			Description
No.	ICE0500		ICE0605	ICE0606	
1	9181085-12		9181112-12	9181112-11	Compressor RED=NLA
2	9151123-03		9151123-04	9151123-04	Hot Gas Valve Coil
3	9151123-01		9151123-01	9151123-01	Hot Gas Valve Body
4	9041104-101A		9041104-101A	9041104-101A	Low Pressure Control
5	9151163-03		9151163-03	9151163-03	Filter Drier
6	9041105-01		9041105-02	9041105-02	Purge Valve - 9041086 is NLA
6.1	9041105-101		9041105-101	9041105-101	Purge Valve Mounting Bracket
7	9091074-01		9091074-01	9091074-01	Drop Adapter
8	9091083-01		9091083-01	9091083-01	Water Inlet Fitting
9	9091140-01		9091140-01	9091140-01	Purge Drain Fitting
10	9021010-04		9021010-04	9021010-04	Clamp (-04P for 25pk)
11	9151006-08		9151006-08	9151006-08	Expansion Valve NLA
11	9151149-101				Expansion Valve (Beg. Ser. K1)
11			9151151-101	9151151-101	Expansion Valve (Beg. Ser. B2)
12	9051280-06		9051280-06	9051280-06	Purge Drain Hose NLA
13	6021032-01		6021032-01	6021032-01	Tube (2.17 Ft.)
14	9021010-04		9021010-04	9021010-04	Clamp (-04P for 25pk)
15	9041087-03		9041087-03	9041087-03	High Temp Safety NLA
16	9151123-02		9151123-02	9151123-02	Liquid Line Solenoid Body
17	9151123-03		9151123-04	9151123-04	Liquid Line Solenoid Coil
18	9151074-01		9151074-01	9151074-01	Receiver
19	2091197-01		N/A	N/A	Accumulator NLA
20	9151027-04		9151027-04	9151027-04	Mixing Valve
21	9091001-11		9091001-11	9091001-11	Remote Fitting 3/8"
22	9091001-12		9091001-12	9091001-12	Remote Fitting 1/2"
23	9151146-01		N/A	N/A	CPR Valve (9151086-01 is NLA)
24	9041111-01		9041111-01	9041111-01	High Pressure Control 9041051-04 is Obs.
25	9041092-02		9041092-02	9041092-02	Pump Down Control (9041040-01 is NLA)
26	3012724-01		3012724-01	3012724-01	Rear Brace NLA

Note: When installing a 9041105 Series Purge Valve the 9041105-101 Mounting Bracket is required.



Item	Model Number					Description
No.	ICE0250	ICE0400	ICE0406	ICE0500	ICE0606	
1	9101139-03	9101139-03	9101139-03	9101139-03	9101139-03	Purge Switch 1051208-01 is NLA
2	9101195-01	9101195-01	9101195-01	9101195-01	9101195-01	ON-OFF-WASH Switch*
3	9101083-01	9101083-01	9101083-01	9101083-01	9101083-01	Relay Socket
4	9101084-01	9101084-01	9101084-02	9101084-01	9101084-02	Relay
5	9101218-12	9101218-12	9101218-12	9101218-12	9101218-12	Water Pump Cord NLA
6	9101002-07	9101002-07	9101002-04	9101002-07	9101002-04	Contactor
7	9181004-27	9181010-14	9181004-07	9181010-12	9181010-12	Compressor Start Relay
8	9181003-39	9181003-17	9181003-05	9181003-26	9181003-26	Start Capacitor
9	N/A	N/A	N/A	9181009-17	9181009-11	Run Capacitor
10	9101148-01	9101148-01	9101148-01	9101148-01	9101148-01	Timer
11	9041104-101A	9041104-101A	9041104-101A	9041104-101A	9041104-101A	Low Pressure Timer Initiate
12	N/A	N/A	N/A	9041092-02	9041092-02	Pump Down Control**
13	9101124-02	9101124-02	9101124-02	9101124-02	9101124-02	Bin Switch

Note* 9101349-01 ON-OFF-WASH switch is NLA

Note** 9041040-01 is NLA, replace by 9041092-02

Item	Model Number			Description
No.	ICE0305	ICE0405	ICE0605	
1	9101139-03	9101139-03	9101139-03	Purge Switch 1051208-01 is NLA
2	9101195-01	9101195-01	9101195-01	ON-OFF-WASH Switch*
3	9101083-01	9101083-01	9101083-01	Relay Socket
4	9101084-02	9101084-02	9101084-02	Relay
5	9101218-12	9101218-12	9101218-12	Water Pump Cord NLA
6	9101002-04	9101002-04	9101002-04	Contactor NLA
7	9181004-04	9181004-04	9181010-10	Compressor Start Relay
8	9181003-08	9181003-08	9181003-33	Start Capacitor
9	N/A	N/A	9181009-11	Run Capacitor
10	9101148-01	9101148-01	9101148-01	Timer
11	9041104-101A	9041104-101A	9041104-101A	Low Pressure Timer Initiate
12	N/A	N/A	9041092-02	Pump Down Control**
13	9101124-02	9101124-02	9101124-02	Bin Switch


Note* 9101349-01 ON-OFF-WASH switch is NLA

Note** 9041040-01 is NLA, replace by 9041092-02

Compressor Components **RED=NLA-No Replacement**

Model Number					Description
ICE0250	ICE0400	ICE0406	ICE0500	ICE0606	
9181121-11	9181086-11	9181086-12	9181085-12	9181112-11	Compressor
9181005-37	9181005-12	9181005-26	9181005-22	Internal	Overload
9181004-27	9181010-14	9181004-07	9181010-12	9181010-12	Relay
9181003-39	9181003-17	9181003-05	9181003-26	9181003-26	Start Capacitor
N/A	N/A	N/A	9181009-17	9181009-11	Run Capacitor

Model Number				Description
ICE0305	ICE0405	ICE0605		
9181088-11	9181088-11	9181112-12		Compressor
9181005-26	9181005-26	Internal		Overload
9181004-04	9181004-04	9181010-10		Relay
9181003-08	9181003-08	9181003-33		Start Capacitor
N/A	N/A	9181009-11		Run Capacitor



1051210-XXA Reference Page 15 for Specific Model Number and Part Number

- The **1051210-XXA** assembly will fit all ICE Models from October 1999 and EC Models.
- Units installed with a double cam switch, either Field installed or Factory installed will require the complete assembly and a potential wiring change as per the New Wiring Diagram included with the assembly.
- Individual component parts are not available for the **1051210-XXA** assembly.
- Individual component parts are No Longer Available for previous version of the Harvest Assist Assembly
- Parts for the **2061962-XX** Harvest Assist Assembly are not compatible with **1051210-XXA** Harvest Assist Assembly.
- Proper assembly and alignment of the parts is critical to proper operation, this includes cam and probe alignment.

Reference the Model Numbers below for the specific Harvest Assist Assembly


Item No.	Model Number					Description
	ICE0250	ICE0400	ICE0406	ICE0500	ICE0606	
1	1051210-01B	1051210-01B	1051210-02B	1051210-01B	1051210-02B	Complete Assembly
	2061962-01S	2061962-01S	2061962-02S	2061962-01S	2061962-02S	No Longer Available

Item No.	ICE0305	ICE0405	ICE0605	Description
	1051210-02B	1051210-02B	1051210-02B	
1	1051210-02B	1051210-02B	1051210-02B	Complete Assembly
	2061962-02S	2061962-02S	2061962-02S	No Longer Available


1051210-XXA are only supplied as complete assemblies, individual components are not available.

Please reference the above Model Numbers to insure the correct assembly is supplied


THE DUAL CAM SWITCH HARVEST ASSIST ASSEMBLIES ARE NO LONGER AVAILABLE



1051199-01	No Longer Available
1051200-01	No Longer Available
1051201-01	No Longer Available
1051202-01	No Longer Available
1051207-01	No Longer Available



2061962-01S	No Longer Available
2061962-02S	No Longer Available



ICE Series Service Parts

Remote Condenser

Item		Model Number			Description
No.	ICE0605		ICE0500		
	ERC1062		ERC1002		ERC1062
1	9141108-01		9141108-01		9141108-01
2	9131357-01		9131357-01		9131357-01
3	9161110-02		9161110-01		9161110-02
4	9161110-92		9161110-91		9161110-92
5	3012802-01		3012802-01		3012802-01
6	9131356-01		9131356-01		9131356-01
7	3012806-01		3012806-01		3012806-01
8	3012793-01		3012793-01		3012793-01
9	3012804-01		3012804-01		3012804-01
10	3012805-01		3012805-01		3012805-01
11	9091001-07		9091001-07		9091001-07
12	9091001-01		9091001-01		9091001-01
13	3012795-01		3012795-01		3012795-01
14	9091001-10		9091001-10		9091001-10
15	9091001-04		9091001-04		9091001-04
16	9091001-08		9091001-08		9091001-08
17	9091001-02		9091001-02		9091001-02

Red =No Longer Available-No Replacement